

RCI 2004-2008 F-150 Front Skid Plate Installation

1. Locate mounting holes on first and second cross-members and on frame behind tow hooks prior to lifting skid plate into position.
2. Install speed clips in each of the corresponding locations on cross-members using the square openings next to each hole. (Remove factory front skid plate if installed, but OEM speed clips may be reused)

*There may be plugs in the square openings that will need to be removed first.

3. With the help of a second person, lift the plate into position with the upward angle/logo facing forward, and partially thread the two front bolts with washers so that plate is self supported.
4. Once all bolts are started and aligned, fully tighten to OEM specs.

Included Hardware Kit

A.	M10 x 35mm Hex Bolt	4 ea.
B.	M10 speed clip	4 ea.
C.	Washer	4 ea.



ENJOY THE NEW PROTECTION!



Disclaimer: The products sold by RCI Metalworks are intended for off-road use only, should not be modified, and are for use only on the vehicle(s) specifically stated. RCI Metalworks makes no warranties express or implied, including of fitness for a particular purpose or merchantability. RCI Metalworks will not be liable for any damages arising out of the use or misuse of its products. It is the customers' responsibility to ensure the products are safely and properly attached to the vehicle, and all products should be installed by trained professionals. We strive to maintain extremely high quality standards; however, all RCI Metalworks products are individually handcrafted, may vary slightly, and may contain minor imperfections. Due to the nature of raw aluminum, the material may have minor scratches and other blemishes caused by the manufacturing process, especially on the back side of product. RCI Metalworks is constantly seeking to improve its products and reserves the right to make changes to any product.