

# 2003-20 4Runner/ 07-14 FJ Cruiser/ 05-20 Tacoma

## RCI A-Arm Skid Plate Installation

1. Universal Hardware packet includes hardware for 05-20 Tacoma, 03-20 4Runner or 07-14 FJ. **Please see install notes for hardware that will NOT be used on your specific model.**
2. Lift front of vehicle with jacks or ramps, and safely secure it if extra working room is necessary.
3. Before starting installation, insert 3/8" carriage bolts through skid plate and secure them with the 3/8" retainers. The shorter of the two carriage bolts will be at the front of skid (toward welded flange). Use a deep socket or similar and tap them on with a hammer. The retainers are not critical but will make install and removal much easier for one person.
4. Lift A-arm skid plate into position and install washers, lock-washers, and nuts (on top of A-arm, leaving loose enough to adjust plate position).
5. Adjust as necessary, then install 1/4" hex bolt through the elongated slot near the tire. Install fender washers on both sides and locknut on top of A-arm. Make sure that there is adequate clearance between CV boot and bolt threads, even at full droop (suspension fully extended). If needed the bolt can be installed upside down, but must be installed while the vehicle is on the ground.
6. Adjust plate as necessary then fully tighten all bolts and locknuts.
7. Repeat steps for opposite A-arm skid plate.

**Enjoy the new protection!!!**

### Included Hardware Kit

A.	3/8" x 3" Carriage Bolt	2 ea.
B.	3/8" x 3-1/2" Carriage Bolt	2 ea.
C.	3/8" x 4" Carriage Bolt	2 ea.
D.	1/4" x 2-3/4" Hex Bolt	2 ea.
E.	1/4" x 3" Hex Bolt	2 ea.
F.	3/8" Washer	4 ea.
G.	3/8" Locknut (or Lock-washer and Hex Nut)	4 ea.
H.	3/8" Retainer Washer	4 ea.
I.	1/4" Fender Washer	4 ea.
J.	1/4" Locknut	2 ea.

### **Install Notes\***

#### 10-20 4Runner/10-14 FJ

- \* Will NOT use the 3/8" x 3" Carriage Bolts
- \* Will NOT use the 1/4" x 2-3/4" Hex Bolts

#### 03-09 4Runner/07-09 FJ/05-20 Tacoma

- \* Will NOT use the 3/8" x 4" Carriage Bolts
- \* Will NOT use the 1/4" x 3" Hex Bolts



Disclaimer: The products sold by RCI Metalworks are intended for off-road use only, should not be modified, and are for use only on the vehicle(s) specifically stated. RCI Metalworks makes no warranties express or implied, including of fitness for a particular purpose or merchantability. RCI Metalworks will not be liable for any damages arising out of the use or misuse of its products. It is the customers' responsibility to ensure the products are safely and properly attached to the vehicle, and all products should be installed by trained professionals. We strive to maintain extremely high quality standards; however, all RCI Metalworks products are individually handcrafted, may vary slightly, and may contain minor imperfections. Due to the nature of raw aluminum, the material may have minor scratches and other blemishes caused by the manufacturing process, especially on the back side of product. RCI Metalworks is constantly seeking to improve its products and reserves the right to make changes to any product.

