

Bed Rack Awning Mount Installation

1. Awning Mount can be installed on either side of bed rack, on the vertical cross-members as well as the horizontal side panels depending on your preference and height requirements. On 12” racks you will need to install brackets toward the top of cross-members and will require using the provided extensions.
2. Install awning brackets using the supplied 3/8” carriage bolts, washers, lock-washers, and nuts.
3. Attach the awning using the hardware supplied by awning manufacturer. Adjust front to back for desired location.
4. Awning brackets are designed for Awnings 25-60 Lbs. and may require a 3rd bracket for extremely large/heavy awnings. Please call us to order if you will need an additional bracket.

Included Hardware Kit

A.	3/8” x 1” Carriage Bolt	4 ea.
B.	3/8” Washer	4 ea.
C.	3/8” Lock-washer	4 ea.
D.	3/8” Hex Nut	4 ea.
E.	5/16” x 3/4” Carriage Bolt	4 ea.
F.	5/16” Washer	4 ea.
G.	5/16” Lock Nut	4 ea.
H.	3/8” x .120 Nylon Spacer	2 ea.



Disclaimer: The products sold by RCI Metalworks are intended for off-road use only, should not be modified, and are for use only on the vehicle(s) specifically stated. RCI Metalworks makes no warranties express or implied, including of fitness for a particular purpose or merchantability. RCI Metalworks will not be liable for any damages arising out of the use or misuse of its products. It is the customers' responsibility to ensure the products are safely and properly attached to the vehicle, and all products should be installed by trained professionals. We strive to maintain extremely high quality standards; however, all RCI Metalworks products are individually handcrafted, may vary slightly, and may contain minor imperfections. Due to the nature of raw aluminum, the material may have minor scratches and other blemishes caused by the manufacturing process, especially on the back side of product. RCI Metalworks is constantly seeking to improve its products and reserves the right to make changes to any product.