


## RCI 25' T4R FUEL SKID

### INSTALLATION GUIDE


ITEM NO.	DESCRIPTION	QTY.
1	.188MS 25 T4R Fuel Skid	1
2	.188MS 25 T4R Fuel Skid Passenger Mount	1
3	.188MS 25 T4R Fuel Skid Driver Mount	1
4	24 LC Fuel skid Hardware Kit	1
4.1	3/8-16 X 1 CARRIAGE BOLT	4
4.2	3/8-16 FIN HEX NUT ZINC	4
4.3	3/8 USS FLAT WASHER THRU HARD	4
4.4	3/8 SPLIT LOCK WASHER ZINC	4
4.5	5/16 USS FLAT WASHER ZINC	4
4.6	M8-1.25 X 20MM HEX FLANGE BOLT	2
4.7	M8-1.25 X 30MM HEX FLANGE BOLT	2



**\*\*Use hand tools, impact wrenches may cause damage if over torqued.\*\***

## **Preparation**

- 1) Remove the OEM skid plate via the 5 bolts shown below.



*Figure 1: OEM skid removal bolt locations.*

## Installation

- 2) Begin by unpacking and removing all components and hardware. Please verify that all hardware and mounting components are present. Reference your original order invoice and verify all items are accounted for.
- 3) If you have purchased sliders, install them first.
- 4) Collect 4)  $\frac{3}{8}$ " x 1" Carriage Bolts, 4)  $\frac{3}{8}$ " washers, 4)  $\frac{3}{8}$ " lock washers, 4)  $\frac{3}{8}$ " nuts, and the driver, and passenger brackets. Assemble the passenger bracket labeled "RCI" and the driver bracket labeled "LC 250 F" and hardware as shown. Leave hardware loose for on vehicle adjustment.





Figure 2: Bracket installation

- 5) Prepare 2) M8 x 20mm bolts, 2) M8 x 30mm bolts, and 4) 5/16" washers. Thread one M8 bolt with washer into the hole that aligns with the assisted slot in the skidplate. Lift the skid into place and slide the slot onto the bolt. Thread the remaining 3 M8 bolts into their respective locations.



*Figure 3: Skid installation*

- 6) Tighten the mounting bolts.  
7) Tighten the lower passenger and driver bracket bolts using a crescent wrench.

**Enjoy your new RCI protection!**



**Share your new install with us on social media!**  
**We love seeing our products out in the wild!**



**[www.rcimetalworks.com](http://www.rcimetalworks.com)**

**[sales@rcioffroad.com](mailto:sales@rcioffroad.com)**

**970-797-3089**



REV: 1 | 9/29/2022

Disclaimer: The products sold by RCI Metalworks are intended for off-road use only, should not be modified, and are for use only on the vehicle(s) specifically stated. RCI Metalworks makes no warranties express or implied, including of fitness for a particular purpose or merchantability. RCI Metalworks will not be liable for any damages arising out of the use or misuse of its products. It is the customers' responsibility to ensure the products are safely and properly attached to the vehicle, and all products should be installed by trained professionals. We strive to maintain extremely high quality standards; however, all RCI Metalworks products are individually handcrafted, may vary slightly, and may contain minor imperfections. Due to the nature of raw aluminum, the material may have minor scratches and other blemishes caused by the manufacturing process, especially on the back side of product. RCI Metalworks is constantly seeking to improve its products and reserves the right to make changes to any product.